



(A) Crown (B) Hours (C) Minutes (D) Second
(E) Day and night

(A) 表的 (B) 时针 (C) 分针 (D) 秒针
(E) 白天&黑夜

INSTRUCTIONS FOR USE

WINDING THE WATCH

1. Your watch has an automatic mechanical movement with 36 hours power reserve. If the watch is stopped for a long time, Without pulling the winding crown out (position 0), wind it clockwise rotate several loops (Wind up 8-10 turn)

SETTING THE TIME

1. pull the winding crown out to the first click (position 1).
2. Set the time.
3. Bring back the winding crown to the original position (0).

使用说明

腕表上链

- 1.您的腕表配有自动上链机械机芯，36小时动力储存。如果腕表停了很长时间，当表冠在位置0，不要将其拔出，顺时针方向旋转几圈（需要上8-10圈）。

设定时间

1. 把上链表冠拔出至（位置1）。
2. 设定时间。
3. 将上链表冠推回原始位置（0）。